

# Werkzeuge

WERKZEUGE

| AKTUALISIEREN |      |            |            |            | WERKZEUGTABELLE ÖFFNEN |      |            |            |            |       |
|---------------|------|------------|------------|------------|------------------------|------|------------|------------|------------|-------|
| T             | NAME | LÄNGE Z    | Ø          | Z-VERSCHL. | T                      | NAME | LÄNGE Z    | Ø          | Z-VERSCHL. | LADEN |
| T001          | ---  | 110.200 mm | 20.000 mm  | 0.000 mm   | T014                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T002          | ---  | 2.000 mm   | 6.000 mm   | 0.000 mm   | T015                   | ---  | 120.000 mm | 200.000 mm | 0.000 mm   |       |
| T003          | ---  | 3.000 mm   | 100.000 mm | 0.000 mm   | T016                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T004          | ---  | 4.000 mm   | 0.000 mm   | 0.000 mm   | T017                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T005          | ---  | 5.000 mm   | 0.000 mm   | 0.000 mm   | T018                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T006          | ---  | 6.000 mm   | 0.000 mm   | 0.000 mm   | T019                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T007          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   | T020                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T008          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   | T021                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T009          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   | T022                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T010          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   | T023                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T011          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   | T024                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T012          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   | T025                   | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |       |
| T013          | ---  | 0.000 mm   | 0.000 mm   | 0.000 mm   |                        |      |            |            |            |       |

HANDBETRIEB

AUTOMATIK

WERKZEUGE

PROGRAMM MGT

DIAGNOSE

ZYKLEN

VERBINDEN

Revision #1  
Created 2026-10-07 18:37:00 UTC by Admin  
Updated 2026-10-07 18:37:09 UTC by Admin